



# NatureWax™ C-3 Poth Hille Code PHC3433

## HANDLING AND MELTING INSTRUCTIONS – CONTAINER CANDLES

**Step One: Melting of Wax** – The wax should be heated to a temperature of 160 to 200°F (71.1 to 93.3°C) to melt the wax. Do not heat the wax above 200°F (93.3°C). If wax is held at higher temperatures for long periods of time, it will discolour. Always use a thermometer when melting the wax and never leave your heated wax unattended. While the wax is melting, stir the wax regularly to reduce localized heating of the wax. This will help to reduce burning of the wax while heating.

**Step Two: Adding of Ingredients (other than Scent and Dye)** – Other additives or ingredients may be added at any time to help improve the performance of the wax.

**Step Three: Adding Candle Scent and Dye** – The fragrances and dyes should be added to the wax after the wax is completely liquid. Make sure to stir the wax completely to ensure that the fragrances and dyes are completely mixed in.

**Step Four: Preparing the Wax for Pouring** - After wax has been completely melted reduce the heat on the wax so that the wax cools to a temperature of 120 to 165°F (48.9 to 73.8°C). This will reduce cracking and discoloration of the wax after it has cooled. Pour Temperature should be matched to ambient room temperature recommendations in the table below for best results.

**Step Five: Pouring Candles** – Make sure that the container is at room or slightly warmer before pouring the wax into the container. The wax should be poured in the container while the wax is 120 to 180°F (48.9 to 82.2°C) to reduce cracking and speed up the cure time of the wax. If the wax is to be left in melter overnight, the wax should be stored at a temperature of 130 to 145°F (54.4 to 62.8°C).

Ambient Room Temperature	Wax Pour Temperature
60 to 70°F (15.6 to 21.1°C)	170 to 180°F (76.7 to 82.2°C).
70 to 80°F (21.1 to 26.7°C)	160 to 170°F (71.1 to 76.7°C).
80 to 90°F (26.7 to 32.2°C)	145 to 155°F (62.8 to 68.3°C).

**Step Six: Curing of Candles** – The candle should be allowed to cool and cure for at least 12 hours before the candle is burned. This will allow the crystals of the wax completely form giving a nice finish to the candle.

### Notes:

- Maximum Recommended Fragrance – 6%
- A 7 to 10% fragrance loads may be added with the addition of additives to help control the fragrance.
- Candles over 3.5 inches in diameter may need to be double wicked to ensure full melt pool.
- Works well with liquid or powdered dyes.

---

The information contained herein is believed to be true and correct under US law. All statements, recommendations or suggestions are made without guarantee, express or implied, and are subject to change without notice. We disclaim all warranties, expressed or implied, including any warranties of merchantability, fitness for a particular purpose and freedom from infringement and disclaim all liability in connection with the use of the products or information contained herein. ©2016 Cargill, incorporated. All rights reserved. (11/16)

